



TiltWatch XTR Tilt Indicator Mounting Instructions

TiltWatch XTR tilt indicators are designed to detect unacceptable tilting of goods that must remain upright.


Using Tilt Indicator WITHOUT Companion Label

Step 1: Peel the adhesive liner from the back of the TiltWatch XTR. Make sure you hold it in an upright position. Once the adhesive liner is removed, the TiltWatch XTR is armed.

Step 2: Place the TiltWatch XTR in an upright position as close as possible to the bottom corner of the shipping container. This placement helps to align the TiltWatch XTR properly and adds rigidity. Apply the TiltWatch XTR to an oil-free surface in an environment above 10°C / 50°F for best results.

Step 3: Press firmly in the centre and around the edges of the TiltWatch XTR to make sure that the adhesive makes good contact with the container it is being applied to.

Tip: Rough wood and heavily waxed wood containers may require special attention. If the wood is extremely rough, we recommend the use of a spray adhesive to increase bonding strength.



TiltWatch XTR Indicator
without Companion Label




Using Tilt Indicator WITH Companion Label

Step 1: Remove the TiltWatch XTR Companion Label from its adhesive liner and place it in an upright position as close as possible to the bottom corner of the shipping container. This placement helps to align the TiltWatch XTR properly and adds rigidity. Apply the TiltWatch XTR Companion Label to an oil-free surface.

Step 2: Peel the adhesive liner from the back of the TiltWatch XTR. Make sure you hold it in an upright position. Once the adhesive liner is removed, the TiltWatch XTR is armed.

Step 3: Place the TiltWatch XTR in the centre of the Companion Label.

Step 4: Press firmly in the centre and around the edges of the TiltWatch XTR to make sure that the adhesive makes good contact with the Companion Label.



Tip: Rough wood and heavily waxed wood containers may require special attention. If the wood is extremely rough, we recommend the use of a spray adhesive to increase bonding strength.



TiltWatch XTR Indicator with Companion Label

Alert Stickers

Every carton of TiltWatch XTR Tilt Indicators also contains 100 Alert Stickers. Place the sticker on the bill of lading / packing slip as a reminder to customers to check the TiltWatch XTR immediately upon arrival.

