


Recommended Placement

L-55 PURPLE - 37G's at 50ms (milliseconds)

PLACEMENT OF LABELS:


- A1. For Packages 50 - 100 lbs (22.68 - 45.36 kg)
Placement is in upper right corner of the package. **See Figure A - A1.**
- A2. For Packages 100-500 lbs (45.36 - 226.8 kg)
Placement is along the right edge, 12-24 inches (30.48 - 60.96 cm) from the bottom of the package. **See Figure A - A2.**

Figure A



- B. If the package is twice as long as it is wide, or palletized shipments use two labels.
Place a second indicator in the same position on the opposite side of the package. **See Figure B.**


Figure B




L-65 YELLOW - 25G's at 50ms (milliseconds)

PLACEMENT OF LABELS:

- A. Place ShockWatch label 12 - 14 in (30.48 - 35.56 cm) from the bottom of the box. Optional: Place a second indicator in the same position on the opposite end of the package.



- B. If the package is twice as long as it is wide, or palletized shipments use two ShockWatch labels. Place a second indicator in the same position on the opposite side of the package.



While these instructions are considered best practices, each situation may be different. If you have any questions, please call (02) 9586 1933 or email solution@shockwatch.com.au